

MAGIC VOICE USER'S GUIDE ERRATA SHEET

This information replaces certain sections in your Magic Voice User's Guide.

1. The following paragraph concerning the RDY command on page 15 will not work as described and should be ignored by the user:

This command can also be used by BASIC programs to detect the presence of a speech module in a system. The variable named "RDY" will be zero when a program is LOADED and RUN if a speech module is not present. If the module is present the value of "RDY" will be -1.

A correct way to detect the presence of MAGIC VOICE while using a BASIC program is as follows. A description of this method is found on page 21 for assembly language programmers.

```
10 IF PEEK(49176)<> 234 THEN GOTO 60:REM CHECK IF MODULE PRESENT
20 IF PEEK(49177)<> 234 THEN GOTO 60
30 IF PEEK(49178)<> 96 THEN GOTO 60
40 SAY1:SAY2:SAY?:REM PUT CODE THAT USES MODULE HERE
50 GOTO 50
60 PRINT"YOU FORGOT YOUR MAGIC VOICE":REM PUT "NO MODULE" CODE HERE
70 END
```

2. We greatly appreciate end-user feedback concerning our products and supporting documentation. Please forward your comments to:

Documentation Support Group
Software Division
Commodore Business Machines, Inc.
West Chester, PA 19380